



9697 East River Rd. NW  
Minneapolis, MN 55433  
763-755-8111

## IMPORTANT INSTRUCTIONS FOR THE CORRECT INSTALLATION OF THE HEAT SHIELDS

*KWIKPFYT will not replace parts improperly installed.*

The KWIKPFYT Heat Shields are designed to protect your brushes from melting due to rear exhaust found on many Trucks & SUV's.

While your flat stainless steel panels face your tow (boat or camper) when mounted, the **Heat Shield Panels will face your exhaust when installed.**

Simply slide the curved upper heat shield panel edge along with one brush per side facing your exhaust system in the exhaust facing channel (See figure 1).

Both Heat Shield and brush should mount flush with the end of outer edge of the KWIK PFYT bar as pictured in figure 2 as does the tow facing (towards the boat or camper) brush and Stainless Steel panel.

The pair of shields you receive will block the exhaust and provide an air gap between the exhaust gasses and the brushes. Make sure the heat shield air gap is positioned behind your tailpipe. Use both **Heat Shields** even if there is only one exhaust pipe will assist the system to remain level as does ensure the gold bolts are tight.

**\*Excessive Idling, especially with Diesel engines may still melt the brushes\***

**\*TIGHTEN ALL ALLEN SCREWS WITH AN ALLEN WRENCH, NOT JUST FINGER TIGHT\***

It is always a good idea to use anti-seize or a product like LOCTITE BLUE to ensure your panels stay where they need to be as vibrations may loosen bolts. **NEVER USE RED Loctite!**

**IF you have any questions at all on any installations please feel free to call us at (763-755-8111) 9am-4PM Central or email us at [info@kwikpfyt.com](mailto:info@kwikpfyt.com).**